

SOME TERMS AND DEFINITIONS

Bore :

Internal diameter of a cylinder.

Top Dead Centre (TDC) :

The extreme upward travel limit of piston.

Bottom Dead Centre (BDC) :

The extreme downward travel limit of piston.

Stroke :

Movement of piston from one dead centre to the other.

Stroke length :

The distance between top and bottom dead centres.

Cubic Capacity (Swept Volume) :

The Volume the piston displaces when it moves from one dead centre to other.

$$= \frac{\pi D^2 l}{4}$$

where, $\pi = 22/7$, $D = \text{Bore}$, $l = \text{Stroke length}$

Clearance Volume :

Volume of the Cylinder above the piston when it is at TDC.

Total Volume :

Volume of the cylinder above the piston when it is at BDC
 = Swept Volume + Clearance Volume

Compression Ratio (CR) :

It is the ratio of the total volume to the clearance volume.
 = Total volume : Clearance volume




Torque (Turning Effort) :

The work crank shaft is capable of doing
 = Cr. arm length x Force.

Maximum torque occurs when maximum fuel burns per cycle in the cylinder in a given engine.

Power :

The rate of doing work.



SOME TERMS AND DEFINITIONS

Horse Power : (HP)

Mechanical unit of power

1 HP = 746 watts.

Brake Horse Power : (BHP)


HP available at the crank shaft for doing usefull work

$$\text{BHP} = \text{Torque} \times \text{Engine speed.}$$

For any given cubic capacity engine, the BHP can be increased by

1. increasing the torque by arranging to burn more fuel per cycle.
2. shifting the peak torque to higher rpm

A Typical BHP, Torque curve :




Valve Timing :

Four Stroke Engines





- IVO - Inlet Valve Opening
- IVC - Inlet Valve Closing
- IVOP - Inlet Valve Open Period
- EVO - Exhaust Valve Opening
- EVC - Exhaust Valve Closing
- EVOP - Exhaust Valve Open Period

Mismatching of timing marks and incorrect tappet adjustment
Change valve timing.



FOUR STROKE CYCLE OPERATION

SPARK IGNITION ENGINES

| | SUCTION STROKE | COMPRESSION STROKE | POWER STROKE | EXHAUST STROKE | | | | | |
|------------------------|---|---|--|---|----------|------|----------|------|----------|
| Inlet Valve | Open | Closed | Closed | Closed | | | | | |
| Exhaust Valve | Closed | Closed | Closed | Open | | | | | |
| Piston Movement | TDC to BDC | BDC to TDC | TDC to BDC | BDC to TDC | | | | | |
| Gas Flow | Air petrol mixture is drawn into cylinder | Air petrol mixture gets compressed. Few degrees BTDC, spark plug produces spark. | Petrol burns. Gas expands. Piston is pushed down. | Exhaust gas flows out. Towards stroke end, fresh charge flows in. | | | | | |
| |  <p>1st stroke</p> |  <p>2nd stroke</p> |  <p>3rd stroke</p> |  <p>4th stroke</p> | | | | | |
| Gas Temperature | 0...120°C | 300...600°C | 2000...3000°C | 1300...1600°C | | | | | |
| Pressure load | 0 to 0.8 kg/cm ² | 8 to 15 kg/cm ² | 30 to 50 kg/cm ² | 4 to 5 kg/cm ² | | | | | |
| Crank angle | 0° TDC | 90° | 180° BDC | 270° | 360° TDC | 450° | 540° BDC | 630° | 720° TDC |
| Crankshaft revolutions | ← ① → | | | | ← ② → | | | | |

TECHNICAL SPECIFICATION

| Sl. No | Item Description | Bullet 350 | Bullet 500 | Lightning 535 | Bullet Mac 350 |
|------------------------------------|-------------------------------|--|-----------------------------|---------------|----------------|
| A DIMENSIONS AND WEIGHTS | | | | | |
| 1 | Length | ←———— 2120mm —————→ | | | |
| 2 | Width | ←———— 750mm —————→ | | | |
| 3 | Height | ←———— 1080mm —————→ | | | |
| 4 | Wheel base | ←———— 1372mm —————→ | | | |
| 5 | Saddle height | 850 mm | ←———— 760mm —————→ | | |
| 6 | Ground clearance | ←———— 140mm —————→ | | | |
| 7 | Vehicle Dry weight | 163kg | ←———— 168kg —————→ | | 163kg |
| 8 | Max. pay load | 175kg | ←———— 185kg —————→ | | 175kg |
| B ENGINE AND ENGINE SYSTEMS | | | | | |
| 1 | Engine Type | ←———— 4 Stroke, spark ignition, air cooled, single cylinder —————→ | | | |
| 2 | Fuel used | ←———— Unleaded petrol —————→ | | | |
| 3 | Catalytic converter | Nil | ←———— Hot tube type —————→ | | Nil |
| 4 | Bore | 70mm | 84mm | 87mm | 70mm |
| 5 | Stroke | ←———— 90mm —————→ | | | |
| 6 | Sweep volume | 346cc | 499cc | 535cc | 346cc |
| 7 | Compression ratio | ←———— 6.5:1 —————→ | | 7.2:1 | 8.5:1 |
| 8 | Max Power @ rpm | 18 BHP @ 5625 | 22 BHP @ 5400 | 25 BHP @ 5500 | 18 BHP @ 5500 |
| 9 | Specific H.P. | 52.02 | 44.08 | 46.72 | 52.02 |
| 10 | Max Torque @ rpm | 27.6 Nm @ 2875 | 35.9 Nm @ 3000 | 38 Nm @ 4000 | 27.6 Nm @ 2875 |
| 11 | Low Idle rpm | ←———— 900 to 1000 —————→ | | | |
| 12 | Starting | ←———— Kick Start —————→ | | | |
| 13 | Cr. Shaft LH bearing | ←———— 6305 & Nu 305 —————→ | | | |
| 14 | Cr. Shaft RH bearing | Nu 205 R | ←———— Nu 205 EC 4 NA —————→ | | |
| 15 | Air filter | ←———— Cotton Gauze —————→ | | | Polyurathane |
| 16 | Carburettor | Micarb VM - 24 | ←———— Micarb VM - 28 —————→ | | PHBH 28 |
| 17 | Main Jet | 90 | 110 | 117.5 | 105 |
| 18 | Pilot jet | ←———— 25 —————→ | | | 38 |
| 19 | Starting jet | ←———— 40 —————→ | | | 70 |
| 20 | Jet block | ←———— 0-8 —————→ | | | |
| 21 | Needle | 4DH7-3 | 4DH7-4 | 5 DHW | 264 T |
| 22 | Needle lock groove from top | III | III | III | II |
| 23 | Air screw turns out (initial) | ←———— 1.5 —————→ | | | 1 |
| 24 | Float height | ←———— 28 to 30mm —————→ | | | 23.5 to 24.5mm |
| 25 | Intake system | ←———— Over head valve —————→ | | | |
| 26 | Lubrication | ←———— Dry sump pressure feed —————→ | | | |
| 27 | Cooling | ←———— Natural air flow —————→ | | | |

TECHNICAL SPECIFICATION

| Sl. No | Item Description | Bullet 350 | Bullet 500 | Lightning 535 | Bullet Mac 350 |
|-----------------------|--|--|--------------------------------|---------------|----------------|
| C PERFORMANCE | | | | | |
| 1 | Cruising speed | ←————— 40-50 —————→ | | | |
| 2 | Max.Speed | 100 | 125 | 130 | 120 |
| 3 | Mileage under normal riding conditions | 35-40 | 30-35 | 34 - 36 | 40-45 |
| D TRANSMISSION | | | | | |
| 1 | Primary Drive | ←————— 3/8" Duplex chain & sprocket —————→ | | | |
| 2 | Engine/ Clutch Drum Sprkt Teeth | ←————— 25/56 —————→ | | | |
| 3 | Primary Reduction | ←————— 2.24:1 —————→ | | | |
| 4 | Clutch | ←————— Wet multiplate —————→ | | | |
| 5 | Gear Box | ←————— Constant Mesh 4 Speed —————→ | | | |
| 6 | Gear ratios: | ←————— I - 2.778:1 —————→ | | | |
| | | ←————— II - 1.842:1 —————→ | | | |
| | | ←————— III - 1.364:1 —————→ | | | |
| | | ←————— IV - 1:1 —————→ | | | |
| 7 | Secondary drive | ←————— Chain and sprocket 5/8" pitch —————→ | | | |
| 8 | Wheel/FD.Spkt teeth | 38/16 | 38/17 | 38/18 | 38/16 |
| 9 | Secondary Ratio | 2.375 : 1 | 2.235 : 1 | 2.11 : 1 | 2.375 : 1 |
| 10 | Drive Chain links | 94 | ←————— 95 —————→ | | 94 |
| 11 | Overall ratio - Max | 14.779 : 1 | 13.907 : 1 | 13.13 : 1 | 14.779 : 1 |
| 12 | Overall ratio - Min | 5.32 : 1 | 5.006 : 1 | 4.726 : 1 | 5.32 : 1 |
| 13 | Main shaft RH bearing | ←————— 6303 —————→ | | | |
| 14 | Main shaft LH bearing | ←————— 6206 —————→ | | | |
| E CHASSIS | | | | | |
| 1 | Frame | ←————— Tubular, welded —————→ | | | |
| 2 | Front suspension | ←————— Telescopic, Hydraulic damped —————→ | | | |
| 3 | Rear suspension | ←————— Swing arm with hydraulic shock absorbers —————→ | | | |
| 4 | Front brake | ←————— 178 mm X 38 mm Twin lead, internal expanding —————→ | | | |
| 5 | Rear brake | ←————— 153 mm X 25 mm, internal expanding —————→ | | | |
| 6 | Rear brake pedal | ←————— LH side —————→ | | | |
| 7 | Wheel bearing Fr & Rr | ←————— 6203 —————→ | | | |
| 8 | Rr. Sprocket bearing | ←————— 6005 —————→ | | | |
| 9 | Front tyre | ←————— 3.25 X 19 - 6 PR —————→ | | | |
| 10 | Rear Tyre | 3.25 X 19 - 6 PR | ←————— 3.50 X 19 - 6 PR —————→ | | |
| 11 | Front tyre Pressure -Solo | ←————— 18 PSI (1.27 Kg/cm ²) —————→ | | | |
| 12 | Front tyre Pressure -Dual | ←————— 20 PSI (1.41 Kg/cm ²) —————→ | | | |
| 13 | Rear tyre Pressure -Solo | ←————— 28 PSI (2.00 Kg/cm ²) —————→ | | | |
| 14 | Rear tyre Pressure -Dual | ←————— 30 PSI (2.11 Kg/cm ²) —————→ | | | |
| 15 | Steering lock | ←————— Inbuilt —————→ | | | |

FE80RS

ISKRA


TECHNICAL SPECIFICATION

| Sl. No | Item Description | Bullet 350 | Bullet 500 | Lightning 535 | Bullet Mac 350 |
|----------|-----------------------------------|--|------------|---------------|-------------------|
| F | CONTROLS | | | | |
| 1 | Steering | ←———— Handle Bar —————→ | | | |
| 2 | Accelerator | ←———— Twist grip on right hand side of handle bar —————→ | | | |
| 3 | Clutch | ←———— Hand lever on LH side of handle bar —————→ | | | |
| 4 | Gears | ←———— Foot lever on RH side —————→ | | | |
| 5 | Front brake | ←———— Hand lever on RH side of handle bar —————→ | | | |
| 6 | Rear brake | ←———— Foot lever on LH side —————→ | | | |
| 7 | Decompressor | ←———— Thumb lever on LH side of handle bar —————→ | | | |
| G | ELECTRICITY AND IGNITION | | | | |
| 1 | Generation | ←———— Alternator 12V 80W —————→ | | | |
| 2 | System | ←———— 12V - AC/DC —————→ | | | |
| 3 | Ignition | ←———— Contact breaker —————→ | | | CDI System |
| 4 | Ignition timing | ←———— 0.8mm BTDC <i>NGK BR 8 ES</i> —————→ | | | 1.8mm BTDC |
| 5 | Spark plug type | MICO W 145Z1 | MICO W5DC | NGK BR 8 ES | MICO W5DC |
| 6 | Spark plug gap | ←———— 0.50mm —————→ | | | 0.70mm |
| 7 | Rotor to stator gap | ←———— 0.15 to 0.25mm —————→ | | | 0.25 to 0.5 mm |
| 8 | Battery | ←———— 12V 5AH —————→ | | | |
| 9 | Head lamp | ←———— 12V 45/40W —————→ | | | |
| 10 | Pilot Lamp | ←12V 2W 2 nos—→ | | 12V, 3.4W | 12V 2W 2 nos |
| 11 | Tail Lamp | ←———— 12V 5W —————→ | | | |
| 12 | Brake lamp | ←———— 12V, 21W —————→ | | | |
| 13 | Turn signal | ←———— 12V 10W —————→ | | | |
| 14 | Speedometer lamp | ←———— 12 X 3.4W —————→ | | | |
| 15 | Ammeter Light | ←———— 12 X 3.4W —————→ | | | |
| 16 | Turn signal Indice | ←———— 12 X 3.4W —————→ | | | |
| 17 | Hi Beam Indicator | ←———— 12 X 3.4W —————→ | | | |
| 18 | Horn | ←———— 12V 3A DC —————→ | | | 12V 3A DC - 2 nos |
| H | OIL AND PETROL | | | | |
| 1 | Engine oil | ←———— SAE 20W-50 —————→ | | | SAE 20W-40 |
| 2 | Performance rating | ←———— API-SE/SF —————→ | | | API-SF |
| 3 | Tank capacity | ←———— 2.25 Litres —————→ | | | 1.65 Litres |
| 4 | Front fork oil | ←———— 10W-30 —————→ | | | |
| 5 | Fr. Fork oil capacity | ←———— 200ml per leg —————→ | | | |
| 6 | Clutch oil | ←———— SAE 10W-30 —————→ | | | 20W-40 |
| 7 | Clutch oil Capacity | ←———— 420ml —————→ | | | |
| 8 | Gear Box Grease (Initial filling) | ←———— Veedol'00' Grade grease —————→ | | | |
| 9 | Gear Box capacity | ←———— 700 Gms —————→ | | | |
| 10 | Fuel tank capacity | ←———— 14.5Litres —————→ | | | |
| 11 | Reserve | ←———— 1.25Litres —————→ | | | |


MAJOR AGGREGATES

ENGINE
346 CC, AIR COOLED, 4 STROKE, SPARK IGNITION ENGINE


TIMING SIDE




DRIVING SIDE




INSIDE VIEW




CYLINDER BLOCK AND CYLINDER HEAD




CRANK SHAFT ASSEMBLY




CONNECTING ROD




PISTON ASSEMBLY




DISTRIBUTOR




AUTOMATIC ADVANCE MECHANISM



CLUTCH




Engaged




Disengaged


GEAR BOX




GEAR BOX OPERATION




Neutral




Third gear



First gear



Top gear




Second gear

- A - CLUTCH ASSEMBLY
- B - MAIN SHAFT
- C - DRIVE SPROCKET
- D - SLEEVE
- E - Ist GEAR ON SLEEVE
- F - IInd GEAR ON SLEEVE
- G - IIIrd GEAR ON SLEEVE
- H - GEAR OPERATOR-INSIDE
- J - GEAR OPERATOR SELECTOR ASSEMBLY
- K - HIGH GEAR
- L - KICK STARTER GEAR
- M - LAY SHAFT
- N - IIIrd GEAR DOG
- P - IIIrd GEAR
- Q - IInd GEAR DOG
- R - IInd GEAR
- S - Ist GEAR


LUBRICATION SYSTEM

DRY SUMP PRESSURE FEED SYSTEM


1. Oil is stored in a oil tank of 2.25 litre capacity. Dipstick with filler cap is provided to check the level and top up as needed.
2. There are two pumps in this system :
 - A. Feed Pump and
 - B. Return Pump
3. Feed pump flow circuit
 - ★ Oil tank ---> Drilled passage ---> Primary gauze filter ---> Feed Pump ---> Oil filter assembly ---> Feed plug on crank shaft ---> Drilled passages on crank shaft ---> Big end bearing ---> Drains to crank case.
 - ★ The oil that drains from big end is thrown around in crank case by the rotating crank shaft to lubricate cylinder walls, piston rings, and the main bearings.
 - ★ Bulk of the oil thrown on cylinder wall is scrapped down by oil scrapper ring.
 - ★ The drained oil gets accumulated in crank case.
4. Return pump flow circuit
 - ★ Crank case ---> Drilled passage ---> Gauze filter ---> Return pump ---> External pipeline ---> Rocker shaft bush
 - ★ From rocker shaft, oil flows to valve assembly ---> push rod tunnel ---> Timing chest.
 - ★ The rotating gears in the timing chest carry oil to lubricate all gears.
 - ★ Then the oil flows to oil tank through the oil return hole on the crank case.



FRONT FORK ASSEMBLY




WHEEL AND HUB ASSEMBLY - FRONT



1. Front Wheel rim (WM 2-19)
2. Front Wheel spokes
3. Front Wheel spokes nipples
4. Front hub assembly
5. Front hub journal bearing (6203)
6. Front hub spindle
7. Front hub felt retainer
8. Front hub felt washer (drum side)
9. Front hub cover plate distance collar
10. Front hub felt washer (speedo side)
11. Front hub felt washer retainer (speedo side)
12. Front hub speedo drive spacing collar
13. Speedo drive complete
14. Front brake shoe c/w lining
15. Front brake shoe spring
16. Front brake cover plate
17. Front brake shoe pin
18. Washer front brake shoe pin
19. Nut front brake shoe pin
20. Front brake operating cam
21. Nut front hub cover plate
22. Front hub spindle nut (speedo side)
23. Front brake operating cam lever
24. Washer front brake operating cam lever
25. Nut front brake operating cam lever S/L


WHEEL AND HUB ASSEMBLY - REAR



- | | |
|--|-----------------------------------|
| 1. Rear wheel rim Wm 2-19 | 9. Rear hub barred 'O' ring |
| 2. Rear wheel spokes (dust cover side-outer) | 10. Rear hub grease seal (small) |
| 3. Rear wheel spokes (dust cover side-inner) | 11. Rear hub journal bearing |
| 4. Rear wheel spokes nipples | 12. Rear hub grease seal (small) |
| 5. Centre hub with barrel | 13. Rear hub spindle (long) |
| 6. Rear hub bearing spacer assy. | 14. Rear hub sprocket cush rubber |
| 7. Rear hub dust cover | 15. Rear hub sprocket 38T |
| 8. Rear hub dust cover screw | 16. Rear hub spindle (short) |

- | |
|---|
| 17. Rear hub bearing (large) |
| 18. Distance collar (dust cover inner side) |
| 19. Rear hub distance collar (dust cover outside) |
| 20. Rear brake shoe c/w lining (bounded) |
| 21. Rear brake shoe spring |
| 22. Rear brake cover plate distance collar |
| 23. Rear brake cover plate assembly |
| 24. Rear hub distance collar (drum side) |
| 25. Rear brake shoe pin |
| 26. Nut rear brake shoe pin |
| 27. Washer rear brake shoe pin (plain) |
| 28. Shoe pin nut rear brake anchor |
| 29. Rear brake operating cam |
| 30. Rear brake cam bush |
| 31. Rear brake operating cam bush pin (long) |
| 32. Rear brake operating cam bush pin (short) |
| 33. Rear brake operating cam bush pin lock nut |
| 34. Rear brake return spring |
| 35. Rear brake operating Cam Lever Assy. |
| 36. Washer rear brake lever |
| 37. Nut rear brake lever |
| 38. Rear hub adjuster (RH) |
| 39. Rear hub adjuster (LH) |
| 40. Locknut (Rear hub spindle) |
| 41. Nut rear hub spindle |
| 42. Rear hub spindle split pin |

TWIN LEAD BRAKE



PERIODICAL MAINTENANCE

The maintenance schedule detailed here will help you maintain your Bullet motorcycle meticulously and to get a long trouble free service. The schedule provided herein is based upon average riding conditions and indicates the Kms at which regular inspections, adjustments, replacements and lubrications are to be carried out. The frequency of the maintenance must be shortened depending upon the severity of the driving conditions or if the motorcycle is used in a very dusty environment. Contact the nearest Royal Enfield Authorised service centre for expert advice and to carry out the required maintenance.

| S. No. | DESCRIPTION | FREE SERVICE Which ever is earlier | | | | PAID SERVICE | | | | | | |
|--------|---|--|-----|---|---|--------------|----|----|----|----|----|----|
| | | Kms (x 1000) | 0.5 | 3 | 6 | 9 | 12 | 15 | 18 | 21 | 24 | 27 |
| | Months | 1.5 | 3 | 6 | 9 | | | | | | | |
| 1 | Engine Oil (Bullet 350 / Electra / 500) | R | R | R | R | R | R | R | R | R | R | R |
| | | Check level every 500 Kms or earlier as required | | | | | | | | | | |
| 2 | Engine Oil (Bullet Machismo) | R | | R | | R | | R | | R | | R |
| | | Check level every 500 Kms or earlier as required | | | | | | | | | | |
| 3 | Engine oil filter (Bullet 350 / Electra / 500) | R | C | C | C | R | C | C | C | R | C | C |
| | Engine oil filter (Bullet Machismo) | C | C | R | C | R | C | R | C | R | C | R |
| 4 | Engine oil strainer (Bullet 350 / Electra / 500) | C | C | C | C | C | C | C | C | C | C | C |
| | Engine oil strainer (Bullet Machismo) | C | | C | | C | | C | | C | | C |
| 5 | Tappets | A | A | A | A | A | A | A | A | A | A | A |
| 6 | CB points (350 / 500 CC) | A | A | A | A | R | A | A | A | R | A | A |
| 7 | Ignition timing (350 / 500 CC) | A | A | A | A | A | A | A | A | A | A | A |
| 8 | Automatic advance system (350 / 500 CC) | L | | L | | L | | L | | L | | L |
| 9 | Spark plug | A | A | A | A | A | R | A | A | A | A | R |
| 10 | HT lead for crack | I | I | I | I | I | I | I | I | I | I | I |
| 11 | Air filter element | C | C | C | C | R | C | C | C | R | C | C |
| 12 | Carburetor | Clean Inspect and Tune | | | | | | | | | | |
| 13 | Fuel filter (350 / Electra / Bullet Machismo) | C | C | R | C | R | C | R | C | R | C | R |
| 14 | Fuel tank | | | C | | C | | C | | C | | C |
| 15 | Breather Box (Bullet Machismo) | Drain Every 3000 Kms | | | | | | | | | | |
| 16 | Fuel hose | I | I | I | I | R | I | I | I | R | I | I |
| 17 | Accelerator cable play | A | A | A | A | A | A | A | A | A | A | A |
| 18 | Rubber hose, Air filter to Carberetor | I | I | I | I | R | I | I | I | R | I | I |
| 19 | Auxiliary air regulatin pipe (Bullet 350 / Electra) | I | I | I | I | R | I | I | I | R | I | I |
| 20 | Braided Hose (500 CC) crack / leaks | I | I | I | I | I | I | I | I | I | I | I |
| 21 | Hose PAV to Inlet manifold (500 CC) crack/leaks | I | I | I | I | R | I | I | I | R | I | I |
| 22 | L' metallic pipe in Inlet Flange (500 CC) crack/leaks | I | I | I | I | I | I | I | I | I | I | I |

A : Adjust C : Clean D : De-carbonise F : Face / Run out I : Inspect L : Lubricate R : Replace
 Note : For maintenance after 30,000 Kms pls repeat the same frequency levels specified above, in consultation with a Royal Enfield Authorised service centre.

| S. No. | DESCRIPTION | FREE SERVICE Which ever is earlier | | | | PAID SERVICE | | | | | | | | | |
|--------|--|---|---|--------|---|--------------|---|---|---|----|----|----|----|----|----|
| | | Kms (x 1000) | | Months | | 0.5 | 3 | 6 | 9 | 12 | 15 | 18 | 21 | 24 | 27 |
| 23 | Rubber Inlet manifold (Bullet Machismo / 500 CC) crack/leaks | I | I | I | R | I | I | I | R | I | I | I | | | |
| 24 | Decompressor cable play | Adjust every 1000 Kms or earlier as required | | | | | | | | | | | | | |
| 25 | Inlet / Exhaust valve seating | | | | | | | | | A | | | | | A |
| 26 | Cylinder head | | | | | | | | | D | | | | | D |
| 27 | Exhaust system | | | | | | | | | D | | | | | D |
| 28 | Primary Chain tension | A | | A | | A | | A | | A | | A | | A | |
| 29 | Clutch oil | R | R | R | R | R | R | R | R | R | R | R | R | R | R |
| | | Check level every 500 Kms or earlier as required | | | | | | | | | | | | | |
| 30 | Clutch free play | Adjust every 1000 Kms or earlier as required | | | | | | | | | | | | | |
| 31 | Gear box grease / oil | | | | | R | | | | | | R | | | |
| | | Check level every 1000 Kms or earlier as required | | | | | | | | | | | | | |
| 32 | Clutch actuating arm | L | L | L | L | L | L | L | L | L | L | L | L | L | L |
| 33 | Rear brake pedal pivot | L | L | L | L | L | L | L | L | L | L | L | L | L | L |
| 34 | Battery terminals (apply petroleum jelly) | C | C | C | C | C | C | C | C | C | C | C | C | C | C |
| 35 | Battery Electrolyte level | I | I | I | I | I | I | I | I | I | I | I | I | I | I |
| 36 | Earth wire eyelet (behind battery carrier) | | | | | I | | | | | | | | | I |
| 37 | Rear Chain | A | A | A | A | A | A | A | A | R | A | A | A | A | A |
| | | Lubricate every 3000 Kms or earlier as required | | | | | | | | | | | | | |
| 38 | Fork oil | | | | | R | | | | | | R | | | |
| | | Check level every 1000 Kms or earlier as required | | | | | | | | | | | | | |
| 39 | Front brake play | Adjust every 1000 Kms or earlier as required | | | | | | | | | | | | | |
| 40 | Rear brake play | Adjust every 1000 Kms or earlier as required | | | | | | | | | | | | | |
| 41 | Front / Rear brake cams | | | L | | L | | L | | L | | L | | L | |
| 42 | Steering ball races | | | | | L | | | | | | L | | | |
| 43 | Spokes tightness | I | | I | | I | | I | | I | | I | | I | |
| 44 | Wheel rim runout | | | I | | I | | I | | I | | I | | I | |
| 45 | Tyre wear | | I | I | I | I | I | I | I | I | I | I | I | I | I |
| 46 | Hand levers & kick starter pivot | Lubricate every 1000 Kms or earlier as required | | | | | | | | | | | | | |

A : Adjust C : Clean D : De-carbonise F : Face / Run out
 I : Inspect L : Lubricate R : Replace

Note :

For maintenance after 30,000 Kms pls repeat the same frequency levels specified above, in consultation with a Royal Enfield Authorised service centre.


PERIODICAL MAINTENANCE

ENGINE OIL


Viscosity - SAE 20W-50

API rating - SE or above

LEVEL CHECK




- ✓ Right Level :
Between 'H' and 'L' of dipstick




- ✓ Top up, if required upto 'H' mark on dipstick

OIL CHANGE : (EVERY 3000 KMS)


- ✓ Keep vehicle on level ground
- ✓ Start the engine and warm up before draining.




- ✓ Drain the oil from oil tank and sump



- ✓ Drain the oil from timing chest




- ✓ Remove the filter




- ✓ Clean the filter


Note : Replace oil filter element every 12000 Kms.




- ✓ Soak the filter in oil for 15 mts.




- ✓ Riffit the filter



- ✓ Tighten the drain plugs and feed plug



- ✓ Fill up with SAE 20W-50 oil
- ✓ Capacity : 2.25 Lits




- ✓ Check level
- ✓ Oil level should be upto 'H' mark

TAPPETS ADJUS™ ENT
(EVERY 3000 KMS)


- ✓ Ensure engine is cold

- ✓ Bring piston to compression stroke TDC


Set by noting the ammeter needle deflection from negative to zero.



- ✓ Remove tappet cover and check push rods.
- ✓ Push rods to be thumb free without up & down play.
- ✓ If incorrect, adjust as follows :




- ✓ Loosen the lock nut



- ✓ Adjust the screw for zero clearance and thumb push rotation
- ✓ Tighten lock nut and check

DECARBONISING (EVERY 12,000 KMS)

Cylinder head




- ✓ Scrub out carbon with a scraper
- ✓ Similarly, decarbonise piston and barrel also

EXHAUST BEND PIPE


MECHANICAL METHOD

- ✓ Take 6 mm wire rope of 70cm length
- ✓ Loosen out splines at one end.
- ✓ Fit the other end to a drill gun



- ✓ Insert it into the pipe and operate the drill.
- ✓ The loose splines of the wire rope will cut and remove the carbon

Chemical method



- ✓ With a potato, close the tube at one end.
- ✓ Prepare a solution by mixing 1 kg. Caustic soda with 8 ltrs. of water.

Note : Prepare the solution in plastic container. Do not allow caustic soda or the solution to come in contact with skin or cloth.

- ✓ Fill the pipe with the solution
- ✓ Keep for 45 to 60 minutes
- ✓ Remove the solution
- ✓ Clean the pipe thoroughly in running water.

AIR FILTER CLEANING


(EVERY 3,000 KMS)



- ✓ Tap - off the dirt



- ✓ Blow compressed air (15 PSI) from inside out



- ✓ Use light to check for cracks / holes / clogging
- ✓ If defective, replace with new.

CARBURETTOR

CLEANING (EVERY 3,000 KMS)


- ✓ Remove the main and pilot jets.
- ✓ Clean with compressed air

FLOAT HEIGHT ADJUSTMENT

(EVERY 3,000 KMS)

Float Height : 28 to 30 mm

- ✓ Remove the float chamber body and gasket
- ✓ Hold the mixing chamber body in inverted position
- ✓ Hold the float so that its tongue just contacts the spring loaded plunger of the float needle valve. Ensure that the spring loaded plunger is not depressed.




- ✓ With a Vernier Caliper, measure the height from the mixing chamber body face to top of the float.

- ✓ If, the float height is incorrect, correct it by bending the float assembly tongue.
- ✓ Check the float height again.


LOW IDLE ADJUSTMENT

(EVERY 3,000 KMS)


Note : Warm up engine before tuning



- ✓ Tighten the air screw fully and loosen it out by one and half turn.
- ✓ Tighten Auxiliary air screw fully.
- ✓ Start and warm up the engine.




- ✓ Set engine speed to 1300 RPM by screwing in throttle stop screw.



- ✓ Loosen the air screw to get highest engine speed

- ✓ Loosen the stop screw and set low idle speed to 900 to 1000 RPM




- ✓ Loosen the auxiliary air screw by half turn. Engine RPM increases.
- ✓ Loosen the throttle stop screw and set idle speed to 900 to 1000 RPM
- ✓ Repeat the above two steps until turning out auxiliary air screw does not increase engine RPM

THROTTLE CABLE FREE PLAY ADJUSTMENT

Free Play : 1 to 2 mm

- ✓ Loosen the lock nut



- ✓ Screw in the cable adjuster to increase the play and screw out the cable adjuster to reduce the play.
- ✓ Tighten the lock nut.

SPARK PLUG

CLEAN AND ADJUST : EVERY 3000 KMS

- ✓ Clean inside with a pointed scraper
- ✓ Measure and adjust the gap to 0.5 mm

GREASING

DISTRIBUTOR SHAFT : (EVERY 3000 KMS)



- ✓ Grease with a grease gun


IGNITION TIMING ADJUSTMENT

(EVERY 3000 KMS) Only for BULLET 350, 500, Lightning 535

- ✓ Remove spark plug



- ✓ Fit dial gauge with adaptor
- ✓ Put a wooden plank under centre stand legs so that rear wheel is lifted from the ground.
- ✓ Engage fourth gear by rotating the rear wheel and shifting the gear lever simultaneously.




- ✓ Rotate the rear wheel as shown and bring the piston to TDC in compression stroke.

- ✓ Maximum clockwise reading of dial gauge indicates TDC.




- ✓ Zero set the dial gauge


BACK PLATE
SLOT



- ✓ Ensure CB back plate screws are at the centre of back plate slots.




- ✓ Clean the CB points
- ✓ Loosen the movable jaw holding screw




- ✓ Adjust the gap. Use a screw driver to move the CB point movable Jaw


- ✓ Set the gap to 0.35 to 0.40 mm




- ✓ Check with a feeler gauge
- ✓ Tighten the screw.




- ✓ Apply a drop of oil onto cam felt.



- ✓ Turn the wheel as shown until the dial gauge needle makes 3 full anticlockwise revolutions.



- ✓ Turn ignition switch 'ON', ammeter will deflect to - ve side.




- ✓ Turn the wheel as shown very slowly...



- ✓ ... Till the needle makes 2.2 clockwise revolution (i.e. 0.8mm before TDC. Needle position as shown above.)


Note: Take care not to cross '20' reading

Note: If the needle crosses '20' reading repeat the above four steps to eliminate timing gears backlash effect on ignition timing.




BACK PLATE HOLDING SCREW

- ✓ Loosen the backplate holding screws and adjust back plate, such that CB point just opens...




- ✓ ... As indicated by ammeter just deflecting back to zero

RETARDING & ADVANCING



- ✓ For retarding.
 - Reduce the CB point gap.
 - Move base plate in clockwise direction.



- ✓ For advancing.
 - Increase the CB point gap
 - Move the base plate in anticlockwise direction.

- ✓ Remove the strips.
- ✓ Rotate the engine to ascertain that the rotor does not come in contact with the stator.

PETROL TANK CLEANING (EVERY 6.000 KMS)


- ✓ Remove the petrol tank
- ✓ Plug the drain hole




- ✓ Pour 500 ml of kerosene




- ✓ Put a handful of carpenter screws in it.



- ✓ Vigorously shake the tank for 2 to 3 minutes.




- ✓ Drain and remove kerosene and the screws.



- ✓ Pour 500 ml of fresh kerosene, shake and drain.
- ✓ Blow compressed air to dry the tank.

CLUTCH

OIL LEVEL CHECK (EVERY 1000 KMS)



- ✓ Loosen / remove the level plug.
- ✓ The clutch oil should slowly ooze out
- ✓ If not, top up with SAE 10 W - 30 oil.

- ✓ Remove the strips.
- ✓ Rotate the engine to ascertain that the rotor does not come in contact with the stator.

PETROL TANK CLEANING (EVERY 6,000 KMS)

- ✓ Remove the petrol tank
- ✓ Plug the drain hole



- ✓ Pour 500 ml of kerosene




- ✓ Put a handful of carpenter screws in it.



- ✓ Vigorously shake the tank for 2 to 3 minutes.




- ✓ Drain and remove kerosene and the screws.



- ✓ Pour 500 ml of fresh kerosene, shake and drain.
- ✓ Blow compressed air to dry the tank.


CLUTCH

OIL LEVEL CHECK (EVERY 1000 KMS)




- ✓ Loosen / remove the level plug.
- ✓ The clutch oil should slowly ooze out
- ✓ If not, top up with SAE 10 W - 30 oil.

OIL CHANGE : (EVERY 3000 KMS)



- ✓ Keep the vehicle on level ground
- ✓ Drain the oil by loosening the chain case cover outer




- ✓ Tighten the chain case cover holding nut
- ✓ Remove the level plug
- ✓ Remove the filler plug
- ✓ Pour SAE 10W - 30 oil through the filler plug
- ✓ ... Till the oil oozes out from the level plug hole



- ✓ Tighten filler and level plugs.


CABLE END OILING : (EVERY 3000 KMS)



- ✓ Lubricate the cable end with a oil can.

GREASING


- ✓ With a grease gun, grease the clutch actuating ARM through the grease nipple



- ✓ Remove the adjuster.
- ✓ Remove the ball and clutch rods from main shaft.
- ✓ Apply grease on then.
- ✓ Refit them.


**CLUTCH CABLE FREE PLAY :
(EVERY 1000 KMS)**

Free play : 2-3 mm



WITH ADJUSTER SCREW


- ✓ Ensure cable adjuster is fully in.



- ✓ Loosen the lock nut
- ✓ Tighten the screw till resistance is felt
- ✓ Now, loosen out by ½ turn
- ✓ Tighten lock nut

WITH ADJUSTER ON CABLE


- ✓ Loosen the lock nut



- ✓ Screw out the adjuster to reduce the play.
- ✓ Screw in the adjuster to increase the play.
- ✓ Tighten the locknut.

PRIMARY CHAIN TENSION ADJUSTMENT (EVERY 3000 KMS)


- ✓ Check the slackness at the centre of the top run.
- ✓ If more, adjust as follows



- ✓ Loosen adjuster lock nut
- ✓ Screw out the adjuster till the right slackness is achieved
- ✓ Tighten the lock nut.

VALVE TIMING

- ✓ Punch marks on crank shaft pinion, exhaust cam wheel and inlet cam wheel are to align when piston is at TDC.
- ✓ Bring the Piston to TDC (The Timing pinion key way will be at 12 'O' clock position)
- ✓ Position the Exhaust cam, aligning its two punch marks with the two punch marks on the timing pinion.



- ✓ Place the inlet cam, aligning its single punch mark with the single punch mark on the exhaust cam.

GEAR BOX

LUB : LEVEL CHECK : (EVERY 3,000 KMS)

- ✓ Remove the level plug


- ✓ The Grease should ooze out.



- ✓ If not, top up with SAE 20 W-50 oil

LUBRICANT CHANGE : (EVERY 12,000 KMS)

- ✓ Start and warm up the engine



Drain the lubricant



Tighten the drain plug



- ✓ Remove the filler and level plugs.


- ✓ Use VEEDOL '00' grease, 700 grams



- ✓ Fill the gear box with veedol '00' grade grease ...




- ✓ Till the grease starts oozing out from the level plug hole.



- ✓ Tighten the filler and level plug

SELECTOR ADJUSTER PLATE ADJUSTMENT




- ✓ Remove the gear box end cover

- ✓ Remove the nuts and the foot control stop plate.
- ✓ Loosen the adjuster plate pins.
- ✓ Move the adjuster plate as required
- ✓ Move the adjuster plate in :
 - ★ Anticlock wise direction to make 1st gear engagement easier.
 - ★ Clock wise direction to make 2nd, 3rd and 4th gear engagement easier.
- ✓ Tighten the adjuster plate pin.
- ✓ Fit foot control stop plate and nut.
- ✓ Fit the gear box end cover

GEAR OPERATOR SELECTOR ASSEMBLY ADJUSTMENT

- ✓ Loosen the lock nut.
- ✓ Tighten the gear operator selector assembly fully.
- ✓ Loosen the gear operator selector till it clicks two times.
- ✓ Tighten the lock nut.
- ✓ Check gear shifting. If tight, loosen the gear operator by one more click.

NEUTRAL FINDER ADJUSTMENT




- ✓ Shift Gear to 4th
- ✓ Depress the neutral lever, while gently turning rear wheel, gear from 4th must fall into the neutral.

- ✓ If it does not fall into the neutral, the neutral lever travel is less.
- ✓ If it crosses through neutral to first gear, the neutral lever travel is more.
- ✓ Loosen the screw of neutral stopper eccentric cam and turn the cam to correct the travel of the neutral finder lever.


REAR CHAIN

SLACKNESS ADJUSTMENT :


- ✓ Check slackness
- ✓ Slackness to be 25 to 30 mm
- ✓ If more or less, adjust as follows :




- ✓ Remove split pin.



- ✓ Loosen Axle nut




- ✓ Loosen spindle nut




- ✓ Loosen anchor nut



- ✓ Loosen the brake rod nut




- ✓ Turn the adjuster cams on both sides till 25 to 30 mm chain slackness is achieved.
- ✓ Check and ensure that the number of notches from the punch mark on the cam to the notch resting on the pin are equal on both sides.



- ✓ Apply brake and tighten all the nuts.

REAR CHAIN CLEANING AND LUBRICATION (EVERY 1000 KMS)

DRIVE CHAIN CLEANING IN—SITU




- ✓ Clean the chain using a clean piece of cloth.
- ✓ Apply SAE 20W - 50 oil liberally on the chain.
- ✓ Rotate the wheel to run the chain several times.
- ✓ Wipe off the excess oil using a clean dry cloth.

AFTER REMOVAL : (EVERY 3000 KMS)



- ✓ Brush and clean the chain in kerosene



- ✓ Hang the chain for 5 minutes to allow the kerosene to drain.



- ✓ Clean with a piece of dry cloth.



- ✓ Heat grease (multipurpose) to 120°C (Appx.)
- ✓ Place the chain in the molten grease.
- ✓ Allow the grease to cool.
- ✓ Remove chain from the grease.




- ✓ Remove the excess grease and clean the chain with a piece of dry cloth

- ✓ While refitting, ensure correct direction of lock link.

FRONT FORK LEVEL CHECK : (EVERY 3000 KMS)



- ✓ Remove plug screw
- ✓ Check oil level with a 5 mm dia rod
- ✓ The level to be 37 to 38 mm



- ✓ Top up, if required.


OIL CHANGE : (EVERY : 12,000 KMS)



- ✓ Remove spring stud nut and drain oil
- ✓ Tighten the spring stud nut.
- ✓ Pour 200 ml of SAE 10 W - 30 oil in each leg.



- ✓ Fit and tighten the plug screw.



- ✓ Bump front fork several times




- ✓ Remove plug screw and check level.
- ✓ Top up, if required.



- ✓ Tighten plug screw

SHOCK ABSORBER ADJUSTMENT


- ✓ The adjuster at the bottom of the spring has five notches.
- ✓ For normal use, keep the adjuster at 3rd notch.



- ✓ Turn the adjuster as shown in the picture for increasing or reducing the spring tension.


- ✓ Increase the spring tension for heavy load and rough road operation.
- ✓ Reduce the spring tension for smooth road and low load operation.
- ✓ Select the same adjuster position for both LH & RH shock absorbers.

**WHEEL RIM
FACE OUT CHECKING**



- ✓ Pre load the dial gauge on to the face of the rim
- ✓ Slowly rotate the wheel.
- ✓ The total indicated reading is the face out.
- ✓ Service Limit : 2 mm

RUN OUT CHECKING



- ✓ Pre load the dial gauge on to the rim inner face.
- ✓ Slowly rotate the wheel.
- ✓ The total indicated reading is the runout.
- ✓ Service Limit : 2 mm.

**REAR SPROCKET DRUM BEARING
GREASING (EVERY : 12,000 KMS)**

- ✓ Remove the sprocket drum assembly.
- ✓ Pack Grease.
- ✓ Replace grease seal with new.
- ✓ Refit the sprocket assembly.

**FRONT BRAKE
ADJUSTMENT**




- ✓ Depress front brake lever fully and check if distance between handgrip and lever is 20 - 30 mm. If gap is less adjust as follows.




- ✓ Loosen the lock nut at the LH fork end and turn out the adjuster screw till the distance from brake lever to hand grip comes to 20 to 30 mm

TWIN LEAD BRAKE ADJUSTMENT

- ✓ Keep the brake in released condition.




- ✓ Loosen link rod nuts 1 & 3.
- ✓ Turn link rod 2 as shown above 3 times.
- ✓ The short lever 4 moves towards release position.
- ✓ Apply the brake and keep it applied.




- ✓ Turn the link rod 2 as shown above.
- ✓ This would move the short lever 4 towards apply direction.
- ✓ Stop turning link rod 2 when high resistance is felt for turning.
- ✓ Tighten the link rod nuts 1 & 3.

**LEVER PIVOT LUBRICATION
(EVERY 3,000 KMS)**



- ✓ Apply few drops of engine oil at the lever pivot.

**REAR BRAKE
PEDAL HEIGHT ADJUSTMENT**



- ✓ Loosen the lock nut.
- ✓ Turn in / out the pedal stop pin till the pedal and foot rest are at the same level.
- ✓ Tighten the lock nut.

PEDAL PLAY ADJUSTMENT

Pedal play - 25 to 35 mm



- ✓ Turn in/out the adjuster nut for correct pedal play.


**BRAKE PEDAL BUSH
GREASING (EVERY 3,000 KMS)**




- ✓ Grease the nipple with a grease gun.

BRAKE CAM GREASING

(EVERY 6,000 KMS)



- ✓ Remove the brake cover plate.
- ✓ Clean the brake cam and apply grease.
- ✓ Refit the cover plate.




- ✓ Loosen crown plate bolts.




- ✓ Tighten stem lock nut.

STEERING PLAY ADJUSTMENT


(EVERY 3,000 KMS)



- ✓ Keep a wooden plank under the stand.
- ✓ Rock the front end and feel the play at stem top end.
- ✓ If felt, adjust as follows :



- ✓ Check play.
- ✓ Steering to be free with out any play.



- ✓ Loosen head lamp casing allen screw.




- ✓ Tighten headlamp casing allen screw.
- ✓ Tighten crown plate bolts.

STEERING BALL RACE LUBRICATION (EVERY 12,000 KMS)

- ✓ Remove steering stem assembly.



- ✓ Clean and check the balls and races thoroughly for damages / pittings / discolouration.
- ✓ Change if defective.




- ✓ Pack grease on the bottom ball race.



- ✓ Pack grease on the top ball race.
- ✓ Assemble the steering stem.


DECOMPRESSOR CABLE PLAY ADJUSTMENT



- ✓ Loosen the lock nut
- ✓ Adjust with adjuster screw till 4 to 5 mm play at lever is achieved.
- ✓ Tighten the lock nut.


CABLE CLEANING

- ✓ Remove the dirt with kerosene as shown.




- ✓ Lubricate with fresh lubricating oil.

WHEEL ALIGNMENT CHECK




- ✓ Hold the vehicle upright off the stand on a level ground

- ✓ Stretch a string about 100 mm above the ground along the wheels.





- ✓ If the string touches two points on the rear wheel and two points on the front wheel (Four point contact) then the wheels are aligned.




- ✓ If the string touches only three points on the two wheels, the alignment is incorrect
- ✓ Adjust the rear wheel, with chain adjuster cam till the string touches four points.

CLEANING AND ASSEMBLY PRECAUTIONS

1. Ensure, the vehicle needs the service you contemplate by proper investigation and analysis
2. Keep the vehicle on a ramp so as to stand and work. People work faster this way.
3. Arrange parts removed in trays, neatly.
4. Inspect all parts, decide the parts you need for servicing and procure it. Only then start assembly.
5. Clean all components (except rubber and electrical parts) in clean kerosene oil mixed with 2% Engine oil.
6. Never use petrol for cleaning. It is costlier and hazardous.
7. Apply lubricating oil on piston, piston ring, and cylinder bore before assembly.
9. Apply oil on threads of bolts and nuts.
10. Replace washers, seals, gaskets and circlips while overhauling.
11. Always use right tools while working to make the work faster, safer and dependable.
12. Use impact screw driver for loosening jammed screws.
13. Heat the aluminium bearing bores for removal and assembly of bearings.
14. Ensure sealing surfaces are clean and free from scoring and warpage.
15. When using liquid gasket, ensure it does not flow into the threaded holes.
16. While assembling, ensure
 - ★ Arrow mark on the piston, faces exhaust side.
 - ★ The open end of the chain lock to face opposite to normal direction of chain rotation.
 - ★ The number of notches from the punch marks of the chain adjuster cams to the notch resting on the pin are to be equal at LH & RH sides.



17. Check for correctness of assembly after each stage.
18. Tighten all nuts and bolts to correct torques.
19. Always smear oil or grease on the oil seal lips before installing.
20. Apply specfit on outer surface of seals to achieve better sealing.
21. Use only recommended oils and grease.
22. Wear goggles and gloves while using grinding machine.
23. Use rubber aprons while working on batteries.
24. Keep a bottle of washing soda water solution (Ratio - 50 gms to one litre water) handy at battery charging area to rinse in case of accidental battery acid spillage.



COMPONENTS INSPECTION

CLEANING

- ★ Mix 2% engine oil with clean kerosene oil
- ★ Clean all components in the above solution
- ★ Dry them with dry compressed air

INSPECTION

Visually inspect the components for the following :

- ★ Breaks
- ★ Cracks
- ★ Scoring
- ★ Scuffing
- ★ Seizure marks
- ★ Bend
- ★ Twist
- ★ Pitting
- ★ Corrossion
- ★ Discolouration

If found ok, check dimensional limits as follows :

Note :

- New components' dimensions to be between new minimum and new maximum
- Replace old parts beyond service limits
- Dimensions are in millimeters (mm)

Pic 3 Piston diameter



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|--------|---------------|-------|
| New Min. | 69.786 | 83.88 | 86.89 | 69.94 |
| New Max. | 69.836 | 83.91 | 86.92 | 69.97 |
| Service limit | 69.636 | 83.725 | 86.73 | 69.85 |

Pic 4 Piston to bore clearance



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.075 | 0.075 | 0.08 | 0.03 |
| New Max. | 0.100 | 0.100 | 0.14 | 0.09 |
| Service limit | 0.175 | 0.175 | 0.42 | 0.30 |

Pic 1 Cylinder bore




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|--------|---------------|-------|
| New Min. | 69.86 | 83.959 | 87.0 | 70.00 |
| New Max. | 69.89 | 83.985 | 87.03 | 70.03 |
| Service limit | 70.00 | 84.125 | 87.15 | 70.15 |

Pic 5 Ring to groove clearance : comp.rings



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.025 | 0.038 | 0.048 | 0.025 |
| New Max. | 0.076 | 0.076 | 0.085 | 0.076 |
| Service limit | 0.15 | 0.178 | 0.178 | 0.15 |

Pic 2 Cylinder bore : point of measurement




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|-----------------------|-----|---------------|-------|
| New Min. | Three points as shown | | | |
| New Max. | | | | |
| Service limit | | | | |

Pic 6 Ring to groove clearance : comp.rings - Middle




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.025 | 0.038 | 0.02 | 0.025 |
| New Max. | 0.076 | 0.076 | 0.057 | 0.076 |
| Service limit | 0.15 | 0.178 | 0.178 | 0.15 |

Pic 7 Ring to groove clearance : Oil ring




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.05 | 0.05 | 0.051 | 0.05 |
| New Max. | 0.10 | 0.20 | 0.096 | 0.10 |
| Service limit | 0.18 | 0.229 | 0.229 | 0.18 |

Pic 11 Piston Pin diameter




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|--------|---------------|--------|
| New Min. | 18.987 | 18.987 | 18.987 | 19.992 |
| New Max. | 18.992 | 18.992 | 18.992 | 19.997 |
| Service limit | 18.982 | 18.982 | 18.982 | 19.982 |

Pic 8 Piston ring end gap : Compression




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.20 | 0.30 | 0.30 | 0.26 |
| New Max. | 0.33 | 0.50 | 0.50 | 0.50 |
| Service limit | 0.75 | 1.00 | 0.75 | 0.80 |

Pic 12 Bigend freeness




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------------------------------|-----|---------------|-------|
| New Min. | Connecting rod to rotate freely | | | |
| New Max. | | | | |
| Service limit | | | | |

Pic 9 Piston Ring end gap: Oil ring




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.20 | 0.30 | 0.25 | 0.30 |
| New Max. | 0.33 | 0.50 | 0.40 | 0.50 |
| Service limit | 0.75 | 1.00 | 1.00 | 0.75 |

Pic 13 Bigend axial play




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.15 | 0.15 | 0.15 | 0.25 |
| New Max. | 0.33 | 0.33 | 0.33 | 0.50 |
| Service limit | 0.55 | 0.55 | 0.55 | 0.60 |

Pic 10 Small end bore




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 19.06 | 19.06 | 19.06 | 20.01 |
| New Max. | 19.07 | 19.07 | 19.07 | 20.02 |
| Service limit | 19.11 | 19.11 | 19.11 | 20.05 |


Pic 14 Crank shaft : Run out



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.04 | 0.04 | 0.04 | 0.04 |
| Service limit | 0.08 | 0.08 | 0.08 | 0.08 |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.05 | 0.05 | 0.05 | 0.05 |
| Service limit | 0.075 | 0.075 | 0.075 | 0.08 |



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.018 | 0.018 | 0.02 | 0.02 |
| New Max. | 0.055 | 0.055 | 0.04 | 0.05 |
| Service limit | 0.075 | 0.075 | 0.06 | 0.08 |

UNIT mm




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 1.73 | 1.73 | 1.73 | 1.73 |
| New Max. | 2.30 | 2.30 | 2.30 | 2.30 |
| Service limit | 2.80 | 2.80 | 2.80 | 2.80 |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 0.043 | 0.043 | 0.04 | 0.04 |
| New Max. | 0.081 | 0.081 | 0.07 | 0.07 |
| Service limit | 0.10 | 0.10 | 0.09 | 1.00 |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.02 | 0.02 | 0.02 | 0.02 |
| Service limit | 0.05 | 0.05 | 0.05 | 0.05 |



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 51.25 | 51.25 | 51.25 | 42.80 |
| New Max. | 51.35 | 51.35 | 51.38 | 44.80 |
| Service limit | 48.20 | 48.20 | 48.20 | 41.50 |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---|---------|-----|---------------|-------|
| Face the surface as shown on the emery paper, spread on surface plate | | | | |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 53.20 | 53.20 | 53.20 | 42.80 |
| New Max. | 53.30 | 53.30 | 53.30 | 44.80 |
| Service limit | 50.04 | 50.04 | 50.04 | 41.50 |

Pic 23 Push tube : Run out




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.02 | 0.02 | 0.02 | 0.02 |
| Service limit | 0.05 | 0.05 | 0.05 | 0.05 |

Pic 26 Spark Plug : Electrode gap




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-----|---------------|-------|
| New Min. | 0.5 | 0.5 | 0.5 | 0.7 |
| New Max. | 0.6 | 0.6 | 0.6 | 0.8 |
| Service limit | | | | |

Pic 24 Valve : Clearance




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|-----------------------------|-----|---------------|-------|
| New Min. | Thumb free (cold) Push tube | | | 0.10 |
| New Max. | | | | 0.10 |
| Service limit | | | | |

Pic 28 Duplex chain : Slackness




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 5.00 | 5.00 | 5.00 | 5.00 |
| New Max. | 6.00 | 6.00 | 6.00 | 6.00 |
| Service limit | | | | |

Pic 25 Rotor to coil : Clearance




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.15 | 0.15 | 0.15 | 0.25 |
| New Max. | 0.25 | 0.25 | 0.25 | 0.50 |
| Service limit | | | | |

Pic 29 Duplex chain : Length across 21 pins




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|--------|---------------|--------|
| New Min. | 191.00 | 190.00 | 190.00 | 190.00 |
| New Max. | 191.00 | 191.00 | 191.00 | 191.00 |
| Service limit | 195.00 | 195.00 | 195.00 | 195.00 |

Pic 26 C.B. Point : Gap



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.35 | 0.35 | 0.35 | N.A. |
| New Max. | 0.40 | 0.40 | 0.40 | N.A. |
| Service limit | | | | N.A. |

Pic 30 Friction plate : Thickness




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 4.70 | 4.70 | 4.70 | 4.70 |
| New Max. | 4.80 | 4.80 | 4.80 | 4.80 |
| Service limit | 4.00 | 4.00 | 4.00 | 4.00 |

Bullet Service Guide


UNIT : mm

Pic 31 Friction plate with insert : thickness




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 4.80 | 4.80 | 4.80 | 4.80 |
| New Max. | 5.10 | 5.10 | 5.10 | 5.10 |
| Service limit | 4.30 | 4.30 | 4.30 | 4.30 |

Pic 35 Rear sprocket : Chain pull off




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | | | | |
| New Max. | | | | |
| Service limit | 5.00 | 5.00 | 5.00 | 5.00 |

Pic 32 Clutch plate : Lug width




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 6.10 | 6.10 | 6.10 | 6.10 |
| New Max. | 6.22 | 6.22 | 6.22 | 6.22 |
| Service limit | 6.00 | 6.00 | 6.00 | 6.00 |

Pic 36 Drive chain : Slackness




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 20.00 | 20.00 | 20.00 | 20.00 |
| New Max. | 30.00 | 30.00 | 30.00 | 30.00 |
| Service limit | | | | |

Pic 33 Clutch steel plate : Distortion




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.05 | 0.05 | 0.05 | 0.05 |
| Service limit | 0.15 | 0.15 | 0.15 | 0.15 |

Pic 37 Drive chain length across 21 pins




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-----|---------------|-------|
| New Min. | 320 | 320 | 320 | 320 |
| New Max. | 322 | 322 | 322 | 322 |
| Service limit | 328 | 328 | 328 | 328 |

Pic 34 Clutch spring : Length



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-------|---------------|-------|
| New Min. | 30.00 | 30.00 | 30.00 | 30.00 |
| New Max. | 31.75 | 31.75 | 31.75 | 31.75 |
| Service limit | 25.50 | 25.50 | 25.50 | 25.50 |

Pic 38 Sprocket




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------------------------|-----|---------------|-------|
| New Min. | Sharp, Bent, Broken teeth | | | |
| New Max. | | | | |
| Service limit | | | | |

Bullet Service Guide


UNIT : mm

Pic 39 Brake drum front : Internal diameter




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|--------|---------------|--------|
| New Min. | 177.80 | 177.80 | 177.80 | 177.80 |
| New Max. | 177.90 | 177.90 | 177.90 | 177.90 |
| Service limit | 178.80 | 178.80 | 178.80 | 178.80 |

Pic 43 Wheel : Face out / Run out




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.10 | 0.10 | 0.10 | 0.10 |
| Service limit | 0.20 | 0.20 | 0.20 | 0.20 |

Pic 40 Brake drum rear : Internal diameter




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|--------|---------------|--------|
| New Min. | 152.40 | 152.40 | 152.40 | 152.40 |
| New Max. | 152.50 | 152.50 | 152.50 | 152.50 |
| Service limit | 153.50 | 153.50 | 153.50 | 153.50 |

Pic 44 Swing arm shaft : Run out




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | | | | |
| Service limit | 0.05 | 0.05 | 0.05 | 0.05 |

Pic 41 Brake lining : Thickness




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 3.80 | 3.80 | 3.80 | 3.80 |
| New Max. | 4.06 | 4.06 | 4.06 | 4.06 |
| Service limit | 2.00 | 2.00 | 2.00 | 2.00 |

Pic 45 Main tube : Run out




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | | | | |
| Service limit | 0.05 | 0.05 | 0.05 | 0.05 |

Pic 42 Axle Shaft : Run out




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | 0.00 | 0.00 | 0.00 | 0.00 |
| New Max. | 0.01 | 0.01 | 0.01 | 0.01 |
| Service limit | 0.02 | 0.02 | 0.02 | 0.02 |


Pic 46 Front fork assembly spring : Length




| | Bul 350 | 500 | Lightning 535 | A 350 |
|----------|---------|-----|---------------|-------|
| New Min. | 538 | 538 | 538 | 538 |
| New Max. | 544 | 544 | 544 | 544 |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-----|---------------|-------|
| New Min. | 2 | 2 | 2 | 2 |
| New Max. | 4 | 4 | 4 | 4 |
| Service limit | | | | |



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|------|---------------|-------|
| New Min. | | | | |
| New Max. | | | | |
| Service limit | 1.00 | 1.00 | 1.00 | 1.00 |



| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-----|---------------|-------|
| New Min. | 1 | 1 | 1 | 1 |
| New Max. | 2 | 2 | 2 | 2 |
| Service limit | | | | |




| | Bul 350 | 500 | Lightning 535 | A 350 |
|---------------|---------|-----|---------------|-------|
| New Min. | 2 | 2 | 2 | Nil |
| New Max. | 5 | 5 | 5 | Nil |
| Service limit | | | | |

CARBURETION

INDICATIONS OF TOO RICH AND TOO LEAN AIR PETROL MIXTURE

| TOO RICH | TOO LEAN |
|--|--|
| <ol style="list-style-type: none"> 1. Engine snatches and revolutions sound heavy 2. Engine running becomes worse on warming up 3. Black carbon accumulation on spark plug tip 4. Excessive bluish white smoke 5. Performance improves on removal of air filter | <ol style="list-style-type: none"> 1. Engine over heats 2. Engine runs better after it warms up 3. Whitish spark plug tip 4. Erratic engine running and jerking 5. Engine runs better when choke is 'ON'. |

EFFECT OF THROTTLE OPENING ON AIR PETROL MIXTURE RATIOS




FLOAT SYSTEM

FUNCTION : To maintain a predetermined level of petrol in float chamber.

FUEL FLOW : Petrol tank ----> Tap ----> Hose ---->
 Carburetor inlet ----> Float Valve -----
 Float chamber <-----



1. Needle valve seat
2. Needle valve
3. Float
4. Float chamber



STARTING SYSTEM

FUNCTION : To supply additional petrol to compensate the condensation of petrol when engine is cold.

FLOW :





1. Venturi
2. Starterjet
3. Emulsion tube
4. Float chamber
5. Air intake port
6. Choke chamber


PILOT SYSTEM

FUNCTION :

To supply Air petrol mixture to the engine from 0 to ½ throttle position

FLO'





1. Throttle valve
2. Venturi
3. Bypass orifice
4. Pilot discharge orifice
5. Pilot jet
6. Air screw


1. Jet needle
2. Main discharge orifice
3. Main jet
4. Emulsion tube
5. Main air passage
6. Air jet

MAIN SYSTEM

FUNCTION :

To supply air petrol mixture to the engine from 1/4 to full throttle open position.


FLOW :



⇨ Air

➔ Petrol

⇨ Air Petrol mixture




WORKING RANGE OF CARBURETTOR COMPONENTS

| ITEMS | THROTTLE POSITION | | | | |
|----------------------------|--|----------|----------|----------|------------|
| | Fully closed | 1/4 OPEN | 1/2 OPEN | 3/4 OPEN | Fully open |
| 1. Air screw and pilot jet | [Active from 1/4 OPEN to 3/4 OPEN] | | | | |
| 2. Throttle valve | [Active from Fully closed to 1/2 OPEN] | | | | |
| 3. Jet needle | [Active from 1/4 OPEN to Fully open] | | | | |
| 4. Main jet | [Active from 1/2 OPEN to Fully open] | | | | |
| 5. Air jet | [Active from 1/4 OPEN to Fully open] | | | | |
| 6. Float system | [Active from Fully closed to Fully open] | | | | |

IGNITION AND ELECTRICALS

EFFECT OF TOO FAR ADVANCED AND RETARDED IGNITION TIMING



A - Too far advanced timing. Causes detonation, pinking and engine over heating.


B - Normal timing

C - Too far retarded timing. Causes incomplete combustion, black smoke, bend pipe over heating and high fuel consumption

BATTERY AND BATTERY MAINTENANCE

Lead Acid Battery has

- | | |
|-----------------|-------------------------------------|
| Positive plates | - Lead peroxide |
| Separator | - Made of insulating material |
| Negative plate | - Sponge lead |
| Electrolyte | - Sulphuric acid + Distilled water. |



Battery stores electrical energy in the form of chemical energy.

Fully charged battery voltage 2.2 per cell

Fully discharged battery voltage 1.75 per cell

Ampere Hours (AH) indicate the capacity of the battery.


Ampere Hour (AH) = Discharging current (A) x Discharging hours (H)

Eg : 10 AH means that it takes 10 Hrs for a fully charged battery to come to fully discharged condition when discharged continuously at a constant rate of one ampere.

Initial Charging :

Electrolyte : Dilute sulphuric acid with distilled water to a specific gravity of 1.240

Preparation :



NOTE : It is important to ensure that the sulphuric acid is added to the distilled water and not vice versa. Stir and check the specific gravity of electrolyte and add sulphuric acid till the specific gravity becomes 1.240

Temperature of electrolyte :

Cool the electrolyte to about 40 deg. C before filling it in the battery upto the maximum level indicated or 2 to 4mm above the plates.

Soaking period :

Keep the battery with electrolyte filled for about half an hour before commencement of charging. Top up the level with electrolyte if necessary. Then put them on charge.

| Battery | Duration | Charging Current |
|----------|----------|------------------|
| 12V 5 Ah | 10 hours | 0.5 Amps. |

Charging :

Charge a used battery when the specific gravity of electrolyte is less than 1.220

Charging Procedure :

1. Top up the electrolyte level with distilled water
2. Connect the positive and negative terminals of battery to the positive and negative terminals of the constant current battery charger.
3. Keep all battery filler caps open.
4. Switch on the power ON/OFF switch and ensure that the charger is operative.
5. Switch on the charging ON/OFF switch
6. Disconnect the battery from the charger when fully charged.

Indication of full charge :

1. Free gassing from electrolyte for more than 90 minutes
2. 3 consecutive reading taken in intervals of 30 minutes each to read constantly 1.240 specific gravity.
3. Voltage : 6V Battery - 6.6 V; 12V Battery - 13.2 V

Precautions :

1. Wear rubber apron while working at battery charging.
2. Use only constant current battery charger of correct charging rate.
3. Never remove the filler cap seals, till you are ready to charge the battery. Hydration may occur when atmospheric air contacts the plates.
4. Keep the filler caps removed while charging.
5. Use only distilled water to top up the level after the initial charging.
6. During charging, the electrolyte temperature should not exceed 45°C If necessary, discontinue the charging to cool the electrolyte.
7. Ensure that the batteries are kept on a non-metallic surface while charging.
8. Keep fire and spark away from battery charging area.
9. Be sure to connect the long vent tube to the battery. While fixing it to the motorcycle route it correctly.
10. Avoid running the motorcycle without connecting the battery.

BATTERY MAINTENANCE


1. Check the electrolyte level and top up, if necessary to the mark or 2 to 4 mm above the separator with distilled water every week.

Important Note : For topping up, use only distilled water.

2. Keep the battery surface clean and dry.
3. Never over charge the battery - it damages the battery.
4. Remove the battery from the motorcycle and store it separately when the motorcycle is not in operation for more than one month.
5. Recharge stored batteries once a month.
6. Check the terminals and cables for corrosion. Apply petroleum jelly on terminals to prevent corrosion.

HYDROMETER :

Hydrometer is used to check specific gravity of electrolyte. The float graduation in level with the electrolyte in it, is the specific gravity of the electrolyte.



BATTERY PROBLEMS

Sulphation :

The active materials in the plates are converted into lead sulphate during discharge. This lead sulphate is reconverted to active materials during recharge. If the battery remains in discharged condition for long periods or excess quantity of acid is used in the electrolyte, the lead sulphate is converted to hard crystalline substance. This is sulphation.

Sulphated batteries do not take normal charging i.e, during charging the lead sulphate will not get reconverted to active materials. Such batteries may show normal voltage with out load, but do not take load.

Hydration :

The positive and negative plates remain submerged in electrolyte. However, when electrolyte level is less than the minimum indicate, the active materials on the plate get exposed to atmospheric air. The active materials, then reacts with water vapour of the atmosphere, forming white spots on the plate. This is hydration.

Hydration reduces the active area on the plates for chemical reaction. This reduces battery capacity.

Shedding :

The active material of the plates falling off is shedding. Over charging and rough handling are the main causes for it. Over charging of the battery also may cause buckling of the plates, rendering the battery unserviceable. Over charging means charging of the battery with excessive current.

SPARK PLUG

Spark plug is a vital part of ignition system. They are subjected to high combustion pressure (around 40 times the atmospheric pressure), intense heat (more than 2000 deg.c. temperature) and severe vibrations. Use of specified spark plug is therefore very important for good performance of an engine.

HEAT RANGE


The spark plug is selected such that its electrodes withstand the operating temperatures of the engine - hot enough to prevent fouling but cold enough to avoid auto ignition.

HOT PLUG

Spark plug with large insulator tip surface area. Central electrode remain hotter.

COLD PLUG

Spark plug with less insulator tip surface area. Central electrode cools faster.



| Vehicle Usage | Spark Plug Recommended |
|---|------------------------|
| 1. Normal driving, both in city and highway | Normal recommendation |
| 2. Mostly stop and go city driving | Use hotter plug |
| 3. Mostly heavy loading, sustained high speed | Use colder plug |

SPARK PLUG ELECTRODE TEMPERATURE


- Below 450 deg.C - Rapid spark plug fouling leading to misfiring
 - Cause - Use of spark plug colder than required
- 450 deq.C - Self cleaning temperature.
- 450 to 850 deg.C - Normal. Burns combustion residues that come in contact with electrodes. Remain clean for long periods.
- 850 deg.C - Auto ignition temperature.
- Above 850 degg.C - Causes pre-ignition, electrode melting and blisters on insulator surface.
 - Cause - Use of spark plug hotter than required.

CYLINDER HEAD AND SPARK PLUG REACH RELATION

ONE GASKET :

①

Correct plug seat



NO GASKET :

②

Carbon deposit on exposed thread. Removal of plug from cylinder head damages cylinder head thread. Earth electrode gets over heated.

TWO GASKET :

③

Results in cylinder threads becoming filled with combustion residue.

LONG REACH SPARK PLUG, IN A CYLINDER HEAD DESIGNED FOR SHORT REACH PLUG


④




- ★ Over heating
- ★ Pre-ignition
- ★ Damage to piston
- ★ Spark plug removal difficult



SHORT REACH SPARK PLUG, IN A CYLINDER HEAD DESIGNED FOR LONG REACH PLUG

⑤

- ★ Starting problem
- ★ Mis-firing
- ★ Difficult in fitmet of new spark plug due to residue on cylinder head threads.



| Spark plug Tip colour | Indication | Figure |
|--|--|---|
| 1. Dark Brown Brown Yellow Brown Light Brown Greyish Brown | ★ Normal combustion ★ Correct running of engine |  |
| 2. Shining black wet carbon depoists | ★ Oil fouling ★ Oil leakage to combustion chamber. |  |
| 3. Whitsh Brown to Whitish Grey | ★ Engine is running in slightly over heated condition |  |



| | | |
|--|---|---|
| <p>4. Dull black, velvety carbon deposits</p> | <p>Incomplete combustion of fuel due to :</p> <ul style="list-style-type: none"> ★ Too rich air petrol mixture ★ Retarded ignition timing ★ Continuous low speed operation ★ Excessive electrode gap ★ Colder spark plug ★ Low H.T. voltage |  |
| <p>5. Melted electrode and blistered porcelain insulator tip</p> | <p>Over heated engine and overheated spark plug due to :</p> <ul style="list-style-type: none"> ★ Too lean air petrol mixture ★ Use of hot spark plug ★ Use of longer reach spark plug ★ Excessive carbon deposit in cylinder or exhaust system. ★ Too far advanced ignition timing. |  |

SPARK PLUG MAINTENANCE



Neglecting the spark plug maintenance eventually leads to difficult starting and poor performance. If the spark plug is used for a long period, the electrode gradually burns away and carbon builds up along the inside part. Once in 3000 Kms or earlier, the plug should be removed for inspection, cleaning and resetting the gap.

Carbon deposits on the spark plug establish a 'shunt' between center and earth electrodes, that prevents good sparking and causes misfiring. Clean the deposits off periodically, with a spark plug cleaning tool/machine.

Check spark plug for worn out earth and center electrodes. If the earth electrode has worn off to a knife edge and center electrode has reduced in height, replace it with new.

| Spark Plug cleaning | Electrode Gap checking |
|---|--|
|  |  |

ELECTRICAL COMPONENTS INSPECTION

| 12V, AC / DC | 12V, DC | | |
|--|--|---|---|
|  | <p style="text-align: center;">Stator coil output wire colours</p> <ul style="list-style-type: none"> V - Violet W - White G - Green Y - Yellow A - Amber  | | |
| <p>CONTINUITY CHECK</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <p>V - V → YES → OK</p> <p>Y - A → YES → OK</p> </td> <td style="width: 50%; vertical-align: top;"> <p>W - G → YES → OK</p> <p>W - V → YES → OK</p> <p>G - V → YES → OK</p> </td> </tr> </table> <p style="text-align: center;">If NO, open Circuit. Check & Correct</p> | | <p>V - V → YES → OK</p> <p>Y - A → YES → OK</p> | <p>W - G → YES → OK</p> <p>W - V → YES → OK</p> <p>G - V → YES → OK</p> |
| <p>V - V → YES → OK</p> <p>Y - A → YES → OK</p> | <p>W - G → YES → OK</p> <p>W - V → YES → OK</p> <p>G - V → YES → OK</p> | | |
| <p>V - Y → NO → OK</p> <p style="text-align: center;">If YES, short circuit. Check & Correct</p> | | | |
| <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <p>V - EARTH → NO → OK</p> <p>Y - EARTH → NO → OK</p> </td> <td style="width: 50%; vertical-align: top;"> <p>W - G → YES → OK</p> <p>W - V → YES → OK</p> <p>G - V → YES → OK</p> </td> </tr> </table> <p style="text-align: center;">If YES, short circuit. Check & Correct.</p> | | <p>V - EARTH → NO → OK</p> <p>Y - EARTH → NO → OK</p> | <p>W - G → YES → OK</p> <p>W - V → YES → OK</p> <p>G - V → YES → OK</p> |
| <p>V - EARTH → NO → OK</p> <p>Y - EARTH → NO → OK</p> | <p>W - G → YES → OK</p> <p>W - V → YES → OK</p> <p>G - V → YES → OK</p> | | |
| <p>RESISTANCE CHECK</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 50%; vertical-align: top;"> <p>V - V → 0.5 to 0.7 Ohms</p> <p>Y - A → 0.5 to 0.7 Ohms</p> </td> <td style="width: 50%; vertical-align: top;"> <p>W - G → 0.5 to 1.0 Ohms</p> <p>W - V → 1.0 to 2.0 Ohms</p> </td> </tr> </table> | | <p>V - V → 0.5 to 0.7 Ohms</p> <p>Y - A → 0.5 to 0.7 Ohms</p> | <p>W - G → 0.5 to 1.0 Ohms</p> <p>W - V → 1.0 to 2.0 Ohms</p> |
| <p>V - V → 0.5 to 0.7 Ohms</p> <p>Y - A → 0.5 to 0.7 Ohms</p> | <p>W - G → 0.5 to 1.0 Ohms</p> <p>W - V → 1.0 to 2.0 Ohms</p> | | |
| <p>VOLTAGE OUTPUT CHECK</p> <p>Across 'Y' & 'A', with head lights on, at 2000 rpm, minimum out put - 13 volts.</p> <p>Across 'V' & 'V', with Trafficator and stop lamp on at 2000 rpm - minimum output - 13 Volts.</p> <p>Connect 'V' with 'G'. Across VG & W, with head lights on, at 2000 rpm, minimum output - 13 volts</p> | | | |

IGNITION SWITCH

| | | | | | | | |
|-----|---|---|---|---|----|----|----|
| | 2 | 4 | 6 | 8 | 11 | 13 | 15 |
| EMG | ● | ● | | | | | ● |
| OFF | | | | ● | ● | | |
| ON | ● | ● | ● | | ● | ● | |

MAIN SWITCH

| | | | | | | | |
|-----|---|---|---|---|---|---|---|
| | 1 | 2 | 3 | 4 | 5 | 7 | R |
| OFF | | | | ● | ● | ● | ● |
| P | | | ● | ● | ● | | |
| H | ● | ● | ● | ● | ● | ● | ● |

LH CONTROL MODULE

| LIGHTS | | | | | | TRAFICATOR | | | HORN | |
|--------|----|----|----|----|----|------------|-----|---|------|----|
| 4 | 5 | N | 14 | 3 | 2 | 1 | | | | |
| Y | YR | BU | G | Gr | RW | Cr/B | LH | 7 | RH | 6 |
| OFF | | | | | | | | | | |
| PD | | | | ○ | ○ | ○ | LH | ○ | ○ | ON |
| ON | ○ | ○ | | ○ | ○ | | OFF | | | |
| N | ○ | ○ | | | | | | | ○ | ○ |
| Lt | ○ | ○ | ○ | | | | | | | |
| FL | | | ○ | ○ | ○ | ○ | | | | |

IGNITION SWITCH

| | | | | |
|-----|------|---|---|---|
| | R.B. | B | R | R |
| OFF | ● | ● | | |
| ON | | | ● | ● |

CONTINUITY CHECK

Continuity between terminals as shown

Continuity between terminals not connected

No continuity between terminals connected

—— SWITCH OK

—— SHORTING

—— OPEN CIRCUIT



SWITCH
NOT OK

SPARK PLUG

- Clean the electrodes and set gap to 0.5 mm
- Clean the plug in a 'Spark plug cleaner cum Tester'
- Test the plug for proper sparking in the tester

Light blue, solid, continuous spark seen in the mirror of the tester


Yellow or red spark; intermittant or no spark; or side spark as seen in the tester mirror

SPARK PLUG
OK


SPARK PLUG
NOT OK

BATTERY

VOLTAGE CHECK



SPECIFIC GRAVITY (SG) CHECK



| | VOLTAGE | | SPECIFIC GRAVITY | |
|-------------|---------------|------------------|------------------|------------------|
| | Fully charged | Fully discharged | Fully charged | Fully discharged |
| 12V Battery | 13.2 | 10.8 | 1.24 | 1.22 |


H.T. COIL

Primary winding resistance (A-B) 3 to 4 Ohms
 Secondary winding resistance (A-C) 7 to 8 Kilo Ohms



RECTIFIER

CONTINUITY CHECK




MULTIMETER

| - VE TO TOUCH | + VE TO TOUCH | INDICATION SHOULD BE |
|---------------|---------------|----------------------|
| V | B | ON |
| B | V | OFF |
| V | B | ON |
| B | V | OFF |
| R/Y | V | ON |
| V | R/Y | OFF |
| R/Y | G | ON |
| V | R/Y | OFF |

CONDENSER

Select OHM meter (Ohm Scale) in multimeter
 Discharge the condenser by touchin its body with its lead
 Touch condenser's body with one probe and condenser's lead with the other probe of the multimeter.

The multimeter needle deflects and returns → **OK**
 The needle does not move at all }
 The needle moves and remains there } → **NOT OK**




SYMBOLS


ELECTRICAL SYMBOLS

| | | | |
|-----|------------------------------|-----|--|
| 01. | Connection | ... | |
| 02. | Ground | ... | |
| 03. | Coil | ... | |
| 04. | Resistor | ... | |
| 05. | Capacitor | ... | |
| 06. | Battery | ... | |
| 07. | Cell | ... | |
| 08. | Armature and brush | ... | |
| 09. | Voltmeter | ... | |
| 10. | Ammeter | ... | |
| 11. | Wired across | ... | |
| 12. | Switch | ... | |
| 13. | Transformer | ... | |
| 14. | Fuse | ... | |
| 15. | Bulb | ... | |
| 16. | Recitifier | ... | |
| 17. | Zener diode | ... | |
| 18. | Silicon controlled rectifier | ... | |
| 19. | Transistor | ... | |
| 20. | Alternating current | ... | |
| 21. | Direct current | ... | |

12V, AC, DC



12V, DC (350 STD)



COMPRESSION TEST

Leakage of compressed air petrol mixture reduces the compression pressure. The leakages can take place either downwards to crank case or upwards through cylinder head.

Down ward leaks (Blow-by) occurs due to :

- * Worn out/scored piston rings, cylinder bore.
- * Excessive clearance between piston and cylinder
- * Scored ring groove land on piston.

Upward leaks occurs due to :

- * Loose cylinder head nuts
- * Blown cylinder head gasket
- * Leaky valve seating
- * Leaky decompressor valve

Compression test enables us to understand :

- * Whether any excessive leak is present.
- * If yes, is it towards the bottom or top.

PROCEDURE

1. Clean and fit the air filter.
2. Ensure clutch operates well.
3. Start and warm up the engine.
4. Switch off the engine.
5. Remove the spark plug.
6. Hold the compression gauge pressed on to the spark plug hole.



7. Hold throttle on full open position.
8. Smartly kick the kick starter pedal two or three times.
9. Remove gauge and check the compression pressure in the gauge.

COMPRESSION PRESSURE :

Bullet : 90 To 115 PSI

Lightning 535 : 110 to 130 PSI

Causes for excessive compression pressure :

- Carbon deposit in the cylinder.
- Use of thinner cylinder head gasket
- Facing of cylinder head / block.

Lower compression pressure indicates compression leakage. To determine whether the leakage occurs towards the bottom or to the top, a 'wet' compression test is to be taken.

PROCEDURE

1. Introduce some lub. oil to the engine (two strokes with an oil can will do)
2. Press the decompressor and crank the engine two or three times.
3. Then take the compression reading as explained earlier.

In wet test, if the compression pressure is higher only upto 5 PSI from that of dry test, the leakage is from : Valves, decompressor plunger and / or cylinder head gasket. If the wet reading pressure is higher by more than 5 PSI, the leakage occurs towards the bottom.

Unit : Nm

| Sl. No. | Item Description | Torque | |
|------------------------------|-----------------------------------|-----------|------|
| | | 350 & 500 | A350 |
| ENGINE | | | |
| 1. | Crank pin nut 7/8" | 138 | -- |
| 2. | Crank shaft pinion nut (Worm nut) | 92 | 92 |
| 3. | Crank case stud nuts ¼" | 9 | 9 |
| 4. | Crank case stud nuts 5/16 | 11 | 11 |
| 5. | Cylinder base stud | 5 | 5 |
| 6. | Cylinder base stud nut | 9 | 9 |
| 7. | Crank case drain plugs | 30 | 11 |
| 8. | Cylinder head mounting studs | 12 | 12 |
| 9. | Cylinder head nuts | 33 | 24 |
| 10. | Tappet guide | -- | 50 |
| 11. | Tappet cover nuts | -- | 8 |
| 12. | Timing cover screws | 10 | 10 |
| 13. | Oil filter stud | 8 | 8 |
| 14. | Oil filter cover nut | 14 | 12 |
| 15. | Oil pipe banjo bolts | 17 | 17 |
| 16. | Rocker cover screws/nuts | 14.5 | 7 |
| 17. | Spark Plug | 20 | 20 |
| 18. | Front drive sprocket nut | 55 | 55 |
| 19. | Alternator rotor nut | 55 | 54 |
| 20. | Exhaust pipe mounting studs | -- | 12 |
| 21. | Exhaust pipe mounting nuts | -- | 6 |
| CLUTCH & GEAR BOX | | | |
| 1. | Clutch centre mounting nut | 55 | 55 |
| 2. | Gear box end cover bolts ¼" | 10 | 10 |
| 3. | Gear main shaft nut | 65 | 65 |
| CHASSIS | | | |
| 1. | Chain stay stud nuts | 35 | 35 |
| 2. | Head lamp clip bolt | 13 | 13 |
| 3. | Rear hub short spindle nut | 75 | 75 |
| 4. | Wheel axle nuts Fr. & Rr. | 65 | 65 |
| 5. | Brake cam nuts | 20 | 20 |
| 6. | Shock absorber nuts | 25 | 25 |
| 7. | Handle bar bolts | 33 | 33 |